

- INSTRUCTIONS:
1. CUT OUT FLOOR PLYWOOD
 2. CUT OUT FLOOR BRACES
 3. CUT OUT FLOOR DOUBLER (UNDER HINGE 3/4" PLYWOOD 9"X9") SCREW INTO BOTTOM OF FLOOR ASSEMBLY WITH 1 5/8" DRYWALL SCREWS
 4. LAY FLOOR BRACES IN PLACE AS SHOWN, TRACE AROUND THEM WITH PENCIL REMOVE BRACES & PRE-DRILL FLOOR BOARD
 5. ATTACH FLOOR BRACES STARTING WITH THE MAIN TWO THAT RUN FRONT TO BACK. ATTACH ONE AT A TIME, (PRE-DRILL FLOOR BRACES) (PRE-DRILL ALL BRACES TO ACCEPT SCREWS, FAILURE TO DO THIS WILL RESULT IN CRACKING & LOSS OF STRUCTURAL STRENGTH)
 6. APPLY LIQUID NAILS LIBERALLY TO FLOOR BETWEEN BRACES & FLOOR (DO NOT SKIP THIS STEP) IF YOU SKIP THIS STEP YOUR STAND WILL SQUEAK LIKE NO TOMORROW
 7. ATTACH ALL BRACES TO FLOOR USING PLENTY OF LIQUID NAILS

