

- 1. DRILL SEAT POST FOR U CLAMPS AS CLOSE TO TOP AS POSSIBLE
- 2. ATTACH U BOLTS WITH LOCK NUTS, DONT FORGET TO ATTACH YOUR CHAIN & S HOOK (BEND ONLY ONE END OF S HOOK)

